

How to Hand a Door


LEFT HAND
Hinges on Left
- Opens Inward




LEFT HAND REVERSE
Hinges on Left
- Opens Outward




LEFT HAND ACTIVE
Hinges on Left
- Opens Inward




LEFT HAND REVERSE ACTIVE
Hinges on Left
- Opens Outward




RIGHT HAND
Hinges on Right
- Opens Inward




RIGHT HAND REVERSE
Hinges on Right
- Opens Outward



RIGHT HAND ACTIVE
Hinges on Right
- Opens Inward



RIGHT HAND REVERSE ACTIVE
Hinges on Right
- Opens Outward



MW 800-522-2940 JLM WHOLESALE **SE 800-768-6050**